



Oil-Only SonicBonded Roll #WRB150H - 30" x 150', 1 roll/package



SonicBonded Mat Roll controls spills and overspray to help keep floors dry and safe.

- **Fast-Acting for Quick Response:** A layer of MeltBlown polypropylene creates high surface area that enables SonicBonded Mat to quickly soak up liquids on contact.
- **High Absorbency Keeps It on the Job Longer:** A random assembly of large-diameter MeltBlown poly fibers creates a lofty layer. Mat absorbs high volumes of liquid fast. Great for catching overspray or soaking up spills.
- **Ultrasonic Bond Points Keep Mat Intact:** Ultrasonic bond points fuse layers of fibers together — Mat keeps its shape even when completely saturated. Top layer of lint-free SpunBond fabric provides extra strength. "Dimples" add fast-wicking power.
- **Perforations Save Money:** SpunBond top layer allows for better-defined perforations and cleaner, easier tear-offs. Roll is perforated every 7.5" vertically and 17" horizontally.
- **Color-Coded:** Color-coding helps you visually identify the right sorbent for your needs. Bright white designates Oil-Only sorbency for oil and other petroleum-based fluids — but not water; makes it easy to identify when saturated.

WRB150H Specifications

Dimensions:	30" W x 150' L
Shipping Dimensions:	17" W x 30" L x 17" H
Sold as:	1 roll per package
Color:	White
Composition:	Polypropylene
Absorbency:	Up to 55.2 gal. per package
# per Pallet:	15
Basis Weight:	HeavyWeight
Incinerable:	Yes

Metric Equivalent Specifications

Dimensions:	76.2cm W x 46m L
Shipping Dimensions:	43.2cm W x 76.2cm L x 43.2cm H
Absorbency:	Up to 208.9 L per package



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com

WRB150H Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Material Safety Data Sheet (MSDS)



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com