

**IMPORTANT** Read These Instructions Before Use & Save Instructions & Packaging

The Interceptor HEPA filter can be set up to process air that is going into or coming out from beneath cabinets, walls, ceilings and floors. For use with the HP60, INJ01, HP60FDP.

It is important to know that HEPA filters do not make a HEPA system. Only by processing all air negatively, can a HEPA system be achieved. All air is processed before going through the blower in either negative or positive drying modes thus never contaminating equipment.



**IMPORTANT** Safety warnings are located on page 2

Phone: 425-822-3851 Fax: 425-745-8480 Toll Free: 800-257-0797  
or on the web at [www.injectidry.com](http://www.injectidry.com)

# SAFETY WARNINGS

## NOTICE

**DO NOT** operate in an environment over 104° F or 40° C.

**FAILURE** to prevent bulk water from passing through the HP60 blower can cause severe damage to the internal workings of the blower and WILL VOID THE WARRANTY.

**WHEN DRYING NEGATIVELY (AIR IN):** Before running the HP60, attach the main hoseline to truckmount or portable extractor and apply vacuum pressure to the material for at least 15 minutes, or until there is no more bulk water being removed. After this step, it is highly recommended that a Water Separator be used for the first 24 hours to ensure no bulk water is passed through the blower. After that, the Water Separator can be removed. The Interceptor should be used for the duration of the job.

**WHEN DRILLING:** Know what you're drilling. Cavities can contain electrical, plumbing and other services. It is highly recommended that a drill stop be used.

## GRAY & BLACK WATER

**Operators should always follow current IICRC S500 Water Damage Restoration Standards.**

## WARNING

Always wear NIOSH-approved protective equipment when changing the pre-filter or HEPA filter, or when cleaning the roto-molded housing.

Disposal of pre-filters and HEPA filter should be done according to your local regulations.

We recommend changing pre-filters after every job.

INTRODUCTION.....	1
SAFETY WARNINGS.....	2
INTERCEPTOR HEPA FILTER (INF01).....	3
PACKING LIST.....	4
REPLACEMENT FILTER INFO.....	4
SET UP WITH WATER SEPERATOR.....	4
WARRANTY .....	5
CUSTOMER SERVICE .....	5

## INTERCEPTOR HEPA FILTER (INF01)



Remove the section of grey hose from the HP60 AIR IN Main Hose as well as the Main T.



The INTERCEPTOR comes with two sections of its own hose attached. The AIR IN side has a 2" female threaded end and the AIR OUT side has a 2" male threaded fitting on it.



Now remove the PRV & Inline Filter from the camlock fitting (on the AIR IN pipe of the HP60 system).



Attach assembly to AIR OUT side of the INTERCEPTOR (2" male threaded fitting). Now re-install the assembly into the camlock fitting on the HP60 AIR IN pipe.



Thread the Main T onto the AIR IN side of the INTERCEPTOR hose.



Now you are ready to start using by simply attaching the HP60 hoses to the Main T.  
\*See HP60 Warnings before operating.

### NOTICE

**WHEN DRYING NEGATIVELY (AIR IN):** Before running the HP60, attach to truckmount or portable extractor, or Injectidry's Water Separator before applying vacuum pressure to the material for at least 15 minutes or until no more bulk water appears from beneath flooring.



## PACKING LIST



INTERCEPTOR roto-molded AIR IN SIDE - 2" x 24" hose with 2" female threaded fitting installed.	1	
INTERCEPTOR roto-molded AIR OUT SIDE - 2" x 24" hose with 2" male threaded fitting installed.	1	PTFC
HEPA Filter	1	INFR1
Pre- Filter (green and yellow)	1	PF10

## REPLACEMENT FILTER INFO

The HEPA FILTER replacement part number is **INFR1**. It will come with one pre-filter (green and yellow). You can also purchase a 10 pak of pre-filters to extend the life of your INTERCEPTOR HEPA Filter. That part number is **PF10**.

## SET UP WITH WATER SEPARATOR

The Water Separator easily connects to the AIR IN side of the INTERCEPTOR HEPA Filter. Follow the instructions section of the Water Separator for use.



# WARRANTY

## Interceptor Roto-Molded Housing Warranty - 7 Years

Injectidry Systems guarantees the roto-molded housing to be free from defects in materials and workmanship for a period of seven (7) years from the original purchase date. This warranty is subject to the conditions listed below.

**Roto-Molded Housing Warranty:** Injectidry Systems will repair or replace for the original purchaser (at Injectidry's option), the parts necessary to correct any defects in materials and workmanship for a period of seven (7) years. During the first year, Injectidry Systems will cover all material, labor, and shipping costs to and from the service center. The customer is responsible for all labor and shipping costs after one (1) year from the original date of purchase.

**Limitations & Exclusions:** This warranty will not extend to Injectidry products showing any accidental damage, alteration, normal wear, disassembly, lack of proper maintenance, damage from fire or flood, damage from corrosive or other chemicals, improper voltage use, unauthorized repairs, use of non-genuine parts and materials, misuse, or any other causes beyond the control of Injectidry. The warranty obligation extends only to the repairs or replacement of parts found to be defective upon the examination and the decision of Injectidry Systems.

The preceding limitations constitute the entire warranty. No other warranty or responsibility is expressed or implied. The warranty includes legal rights to the original purchaser and is not transferable. Additional rights may be available, varying state to state. In addition, Injectidry Systems Repair Department must authorize all incoming products and/or repair work to be completed by an authorized repair center. Injectidry Systems is not responsible for any repairs or modifications to any of its products, unless completed by Injectidry Systems or an authorized service center. We are not responsible for subsequent damage caused by the user and or its agents.

## CUSTOMER SERVICE

**Return for Repair Request:** You can obtain a Request for Repair Form by calling 800.257.0797 or by going to our website for a form on the "Contact Us" page.

**Return Request:** You can obtain a Request for Return Form by calling 800.257.0797 or by going to our website for a form on the "Contact Us" page.

### Incomplete Shipments

All shortages must be reported within five business days.

Be sure to check the number of cartons or packages. You can compare this count with the total listed on Bill of Lading. Confirm that you have received all cartons or packages pertaining to this shipment.

If quantities do not match, have the delivery driver note shortage. If the missing cartons or packages do not show up in the next few days, contact the Shipping Department and we will reship on a new order.

You must file a Freight Claim for shorted packages if the count differs from the Bill of Lading. For your protection, the carrier who delivers merchandise to your door is responsible for any loss or damages. Acceptance of the shipment by the carrier company is acknowledgement that the articles were delivered to them were in good condition and properly packaged.

### Freight Damage

Orders are shipped Freight on Board (F.O.B.) from our warehouse in Lynnwood, WA. If the customer has chosen to ship the order with their own account and or carrier, the customer will be responsible for the filing of the freight damage claim. If the customer chose to use Injectidry's account/carrier, Injectidry will file the freight damage claim. All freight damage should be reported to the Injectidry Shipping Department immediately upon discovery.

Inspect your shipment upon delivery. Have the driver note all visible damage on the waybill before you sign. If the discovery of damage is found after the driver has left immediately call the carrier.

Injectidry chooses our carriers carefully and strives for your equipment to be delivered in a timely and undamaged condition. If a mistake happens we do all we can to communicate the problem with the carrier so that it is not repeated. Please let us know immediately if you have any problems.

**NOTICE:** Certain uses of heating equipment in conjunction with real-time temperature-monitoring equipment and filtration devices might infringe on certain United States patents and is therefore strongly discouraged. The user is advised to seek legal counsel before use of that combination of equipment. Injectidry Systems, Inc., Seller, does not assume and hereby disclaims liability for patent infringement claims arising from such use. Buyer agrees not to use Seller's equipment, training, literature or advice for the purpose of using heat or inducing others to use heat to destroy organisms, remove toxins from a structure, remediate mold, or kill insects, bacteria, viruses, dust mites, spiders or fungi. Your use of Seller's equipment and/or training services confirms your agreement not to use heat equipment in such a manner.