

UPHOLSTERY SYSTEMS

Natural Fibers

A) Use for: Refined cotton, wool, cotton velvet, silk (water-cleanable), linen, cotton blends, rayon. *Formula used approximately 85% of the time.*

PRESPRAY

1 part **Avenge Fabric Prespray** to 1 part hot water.
(May be used full strength for extra-heavy soil.)
Wool - Wool Perfect 1:16

EXTRACT

Avenge Clean Rinse

Portable: 1 oz. per gal. hot water
Truckmount: 1 qt. per 5 gal. water
Wool - Wool Zone 1 oz. per gal.

PROTECT

Maxim Advanced for Upholstery or **Maxim Fine Fabric** (use straight)

B) Use for: Unrefined cotton, cotton canvas, exotics or any fabric prone to browning, wicking or water marking. *Formula used approximately 10% of the time.*

PRESPRAY

1 part **Avenge Fabric Prespray** to 1 part hot water.
(May be used full strength for extra heavy soil.)

EXTRACT

Fab-Set

Portable: 8 oz. per gal. hot water
Truckmount: 1 qt. per 5 gal. water

PROTECT

Maxim Advanced for Upholstery or **Maxim Fine Fabric** (use straight)

C) Use for: Bleeders: natural or synthetic fibers. *Formula used approximately 5% of the time.*

PRESPRAY

3 oz. **Dye-Loc** per gal. of warm water, dwell one minute, followed by:

PRESPRAY 2

1 part **Avenge Fabric Prespray** to 1 part hot water

EXTRACT

3 oz. **Dye-Loc** per gal. of warm water

PROTECT

Maxim Advanced for Upholstery or **Maxim Fine Fabric** (use straight)



UPHOLSTERY SYSTEMS

Synthetic Fibers

A) Use for: Medium to heavily soiled synthetics such as nylon, olefin and polyester. *Formula used approximately 50% of the time.*

PRESPRAY

1 part **Avenge HD Fabric Prespray** to 1 part hot water

EXTRACT

Avenge Clean Rinse

Portable: 1 oz. per gal. hot water
Truckmount: 1 qt. per 5 gal. water

PROTECT

Maxim Advanced for Upholstery (use straight)

B) Use for: Heavily soiled synthetics with heavy stains and body oils. *This formula used approximately 30% of the time.*

PRESPRAY

Avenge HD Fabric Prespray, do not dilute. Add 1 oz. **Citrus Solv** per gallon of **Avenge HD**

EXTRACT

Avenge Clean Rinse

Portable: 1 oz. per gal. hot water
Truckmount: 1 qt. per 5 gal. water

PROTECT

Maxim Advanced for Upholstery (use straight)

C) Use for: Exceptionally heavy soils, grease and stains on synthetics. *This formula used approximately 20% of the time.*

PRESPRAY

Avenge HD Fabric Prespray, do not dilute. 1 oz. **Boost-All**, dissolve first in qt. of hot water then add to **Avenge HD**, 1 oz. **Citrus Solv** per gallon of **Avenge HD**

EXTRACT

Avenge Clean Rinse

Portable: 1 oz. per gal. hot water
Truckmount: 1 qt. per 5 gal. water

PROTECT

Maxim Advanced for Upholstery (use straight)

